

# Alaska Scientific Crime Detection Laboratory

## DataMaster Check In Form

Issued: 1/13/2017  
Effective: 1/17/2017

Version: DMCIF 2017 R0  
Status: Active

Instrument S/N 100363

Received From Intoximeters

Date 09/14/21

Analyst Derra Walton

1. Reason for instrument return:

Refurbished by manufacturer, repaired for filter wheel errors

2. Change instrument and case location in JusticeTrax Breath Alcohol Database

3. Ensure change in instrument status form is in JusticeTrax

4. Upload

*Na - instrument was not in the field*

5. Update agency information and polling status in DM Host Calling Program

*JMW 09/14/21*

6. Check for VOCs

### From Intoximeters

7. Intoximeters Repair Paperwork (attached)

**SRO Number:** SRO-047141

**Received Date:** 07/26/2021

**Completion Date:** 08/27/2021

**SRO Type:** REPAIR

**SRO Description:** DMT Repair/Preventative Maintenance

**Customer ID:** C000003651

**Customer PO:** 07262021-Lee

**Contact:** Tatiana Lee

**Email:** tatiana.lee@alaska.gov

**Ship To:**

Alaska Department of Public Safety  
Procurement & Supply Section  
4805 Dr. MLK Jr. Avenue  
Anchorage AK 99507

**Units on SRO**

1	LEGDMT	LEGACY DMT
---	--------	------------

<b>Service Line:</b> 1		<b>**All Instruments are Calibrated to Factory Specifications**</b>	
<b>Unit Type:</b>	(LEGDMT) LEGACY DMT		
<b>Serial Number:</b>	50100363		
<b>Reason:</b>	DMT Status Messages		
<b>Reason Notes:</b>	FltWl er		
<b>Resolution:</b>	Customer Reported Issue: Filter Wheel Error		
<b>Resolution Notes:</b>	Cleaned		
	cleaned		
<b>Resolution Notes:</b>	Cleaned, lubricated, & adjusted filter wheel movement parts Optimized detector		
<b>Parts:</b>	<u>Qty</u>	<u>Part Number</u>	<u>Part Description</u>
	2	59-0058-00	DMT ELEC IC RS232 MULTCH U31/33
<b>Reason:</b>	DMT Functional		
<b>Reason Notes:</b>	No Boot		
<b>Resolution:</b>	Instrument software booted normally the first time but not after moving the instrument before PM. It would boot to a blank screen.		
<b>Resolution Notes:</b>	Replaced		
	RPL PCB		
<b>Resolution Notes:</b>	Replaced the SI board		
	1	59-0036-00	DMT HRDW CLIP BREATH TUBE HOLD 37058
<b>Reason:</b>	Preventive Maintenance		
<b>Reason Notes:</b>	planned		
<b>Resolution:</b>	90-8000-00 Prev Maint Contract		
	Prev M		
	planned		

<b>Resolution Notes:</b>	<p>90-8000-00 Prev Maint Contract                  Added BT clip                  Added new O-ring to the BT                  Trimmed 1 inch of unheated tubing                  Installed sample chamber torx mounting screws                  Mounted dual check valve to the side panel                  Cleaned and adjusted the 5-way valve                  Tightened screws on the USB expansion board                  Added metal seal tape to SC mirror blocks                  Installed digital Mod to the control board                  Air volume checked (2.64) and adjusted (3.01)                  Check and or adjusted the time and date                  Replaced used tubing connecting SC to the dual check valve                  Tested modem                  RFI sensitivity</p> <p>Parts                  (2) 59-0058-00 ELEC IC RS232 MULTCH U31/33                  (1) 59-0036-00 HRDW CLIP BREATH TUBE HOLD37058                  (1) 001199-00 ELEC REGULATOR V LDO 3.3V OUT 30V IN                  (1) 59-0076-00 ELEC PCB SI KIT 43602</p> <p>Calibration: Lot# 21080 Bot# 618 exp. 08/Mar/2023                  Dry Gas: AG026705 Bot# 014 exp. 25/Sep/2022</p>		
	1	001199-00	DMT ELEC REGULATOR V LDO 3.3V OUT 30V IN
	1	59-0076-00	DMT ELEC PCB SI KIT 43602
	1	90-8000-00	CONTRACT PREV MAINT DMT

# Order Packing Slip Report

**Intoximeters**  
Experience · Service · Integrity

9/1/2021 1:55:48 PM

**Packing Slip:** 235741

**Pack Date:** 9/1/2021

**SRO:** SRO-047141



**From:** Intoximeters, Inc  
2081 Craig Road  
St Louis MO 63146  
USA

**Customer:** C000003651

**Ship To:** 2

Alaska Department of Public Safety  
4805 Dr MLK Jr Ave  
Anchorage AK 99507  
USA

Alaska Department of Public Safety  
Procurement & Supply Section  
4805 Dr. MLK Jr. Avenue  
Anchorage AK 99507  
USA

**Customer PO:** 07262021-Lee

**Ship Via:** FDX

FED EX

**Weight:** 37.00

**Delivery Terms :** 2D

**Shipping Terms :** ORIGIN

**# Packages:** 1

**Customer Ship Account :**

Line Number	Item	UM	Ordered Quantity	Shipment Quantity	Backorder Quantity
1	LEGDMT	LEGACY DMT			50100363
1	<b>59-0058-00</b>	EA		2.00	0.00
	DMT ELEC IC RS232 MULTCH U31/33				
2	<b>59-0036-00</b>	EA		1.00	0.00
	DMT HRDW CLIP BREATH TUBE HOLD 37058				
3	<b>001199-00</b>	EA		1.00	0.00
	DMT ELEC REGULATOR V LDO 3.3V OUT 30V IN				
4	<b>59-0076-00</b>	EA		1.00	0.00
	DMT ELEC PCB SI KIT 43602				
5	<b>90-8000-00</b>	EA		1.00	0.00
	CONTRACT PREV MAINT DMT				