Alaska Scientific Crime Detection Laboratory

DataMaster Check In Form Issued: 1/13/2017 Version: DMCIF 2017 R0 Effective: 1/17/2017 Status: Active Instrument S/N___ Received From Indoximeters, Inc. Analyst Deren Watton 1. Reason for instrument return: AW 04/03/20 Instrument for returbished by manufacturer, litter wheel 2. Change instrument and case location in JusticeTrax Breath Alcohol Database 3. Ensure change in instrument status form is in JusticeTrax 4. Upload NA - Instrument was not in the field Im 04/03/20 5. Update agency information and polling status in DM Host Calling Program 6. Check for VOCs From Intoximeters

7. Intoximeters Repair Paperwork (attached)

Intoximeters

Experience · Service · Integrity

Service Record

SRO Number: SRO-039493

Received Date: 03/11/2020

Completion Date: 03/18/2020

LEGACY DMT

SRO Type: REPAIR

SRO Description: DMT Repair/Prev Maint

Customer ID: C000003651

Customer PO: 20200108DJW

Contact: Derek Walton

Email: derek.walton@alaska.gov

LEGDMT

Ship To:

Units on SRO

Alaska Scientific Crime Detection Laboratory

4805 Dr MLK Jr Ave Anchorage AK 99507

USA

Service Line:	**All Instruments are Calibrated to Factory Specifications**			
Unit Type:	(LEGDMT) LEGACY DMT			
Serial Number:	50100351			
Reason:	Preventive Maintenance			
	planned			
Reason Notes:	Preventive Maintenance			
Resolution:	Update			
	DMTVR3			
Resolution Notes:	Installed TB-30 modification Replaced R97 on the control board Leak checked dry gas regulator Added epoxy to support filter motor wires Sealed the sample chamber mirror blocks with metal foil tape Adjusted the display stand offs to center the it in the opening Replaced missing press fit nut on top of enclosure Adjusted tech screen settings and RFI sensitivity Check/ replace/Add o ring to end of breath tube Calibrated, Wet and dry Accuracy checked			
	Parts 001199-00 3.3volt regulator 59-0134-00 R97 resistor Calibration solution (0.200) Lot# 19200 Bottle# 388 Dry gas: AG916303, Tank 014, Exp. 12 Jun 2021			

Parts:	<u>Qty</u>	Part Number	Part Description	
	1	001199-00	DMT ELEC REGULATOR V LDO 3.3V OUT 30V IN	
Reason:	DMT Status Messages			
	FltWl er			
Reason Notes:	Customer Reported Issue: Filter wheel error			
Resolution:	Adjusted			
	Mech adj			
Resolution Notes:	Rebuilt filter assembly and added epoxy to motor wires Optimized detector			
	1	90-8000-00	CONTRACT PREV MAINT DMT	
	1	59-0134-00	DMT ELEC RESISTOR R97 01578	

